

WHAT'S IN THE BOX:



CYBERQ CLOUD



POWER PACK



FOOD PROBE



CYBERQ BAG



PIT PROBE

STANDARD KIT




CONTROL MOUNT



FAN

*OPTIONAL GRILL ADAPTOR MAY BE INCLUDED

MONOLITH KIT



SPIRAL FAN CORD



CONTROL MOUNT

CYBERQ CLOUD 4-STEP BASIC SETUP



ATTACH FAN TO YOUR SMOKER USING OPTIONAL GRILL ADAPTOR (IF NECESSARY)

PLUG PIT PROBE INTO CYBERQ CLOUD AND ATTACH OTHER END TO PIT GRATE

PLUG FOOD PROBE INTO CYBERQ CLOUD AND INSERT OTHER END IN YOUR MEAT

PLUG FAN INTO CYBERQ CLOUD AND CONNECT POWER PACK TO CYBERQ CLOUD AND AN AC OUTLET

FOR FULL SPECIFICATIONS AND INFORMATION ON SETTING UP THE CYBERQ CLOUD VISIT KB.BBQGURU.COM



LIMITED WARRANTY

NO USER SERVICEABLE PARTS. CONTACT BBQ GURU FOR SERVICING Equipment is designed for Indoor/outdoor use. Although the CyberQ is water resistant and tested to be safe in wet conditions, it is the user's responsibility to protect the electronics from heavy precipitation and water damage.

CYBERQ CLOUD WI-FI CONTROLS AND FANS (2 Year limited warranty) The BBQ Guru warrants this product to be free from defect in workmanship and materials for a period of 2 years from the date of purchase.

PIT/FOOD PROBES, POWER PACKS, AND OTHER ACCESSORIES (90 day limited warranty) The BBQ Guru warrants these products to be free from defect in workmanship and material for a period of 90 days from the date of purchase.

For full warranty information, please visit www.bbqguru.com


WARNINGS

FIRE WARNING, BURN HAZARD

- Power Draft Fans can get the temperature of your pit higher than through natural draft. Use extra caution in opening your pit and determining its placement. Always inspect your fan and probe wires for damage.
- Even quality electronics can fail and cause the temperature to read incorrectly. Be sure to use a redundant dial thermometer as a backup temperature sensor on your pit.
- Smoke can combust when oxygen is introduced and can produce severe burns. Always use caution when opening the lid or door of your pit.
- Probes will get extremely hot during cooking, and should be handled with a protective mitt or allowed to cool.
- SHOCK HAZARD, HIGH VOLTAGE! The power supply for this product is plugged into a 120 or 240 VAC Mains. THIS VOLTAGE CAN KILL YOU OR HURT YOU. KEEP THE POWER SUPPLY AWAY FROM WATER AND OFF THE GROUND.
- CAUTION: Use only BBQ Guru supplied probes, fans, and power supplies.

To read all safety warnings, please visit kb.bbqguru.com

TEMPERATURE GRAPHING



AMAZON ALEXA VOICE CONTROL

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.



USER SHOULD UNDERSTAND THE SAFE OPERATION OF THEIR GRILLING EQUIPMENT PRIOR TO USING THIS PRODUCT. SERIOUS INJURY AND PROPERTY DAMAGE COULD RESULT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Contains Transmitter Module W70MRF24WG00MAMB
12V ~ 2 A max

LEARN MORE

A full user guide is available at kb.bbqguru.com

NEED HELP?

Email your questions or concerns at customerservice@thebbqguru.com



359 IVYLAND ROAD WARMINSTER, PA 18974

BBQ GURU CYBERQ CLOUD



QUICK START GUIDE




3 WAYS TO OPERATE THE CYBERQ CLOUD:




MANUAL SETUP

MONITOR AND CONTROL COOK DIRECTLY ON CYBERQ CLOUD.



1 When CyberQ Cloud powers up, the LCD panel will display the cook and food temperatures as well as the fan output and timer.



2 Using the arrow buttons on the CyberQ Cloud, navigate through the display options.



3 To set a desired target temperature, navigate to the desired probe, and press the **ENTER** button.



4 Use the **LEFT** and **RIGHT** keys to select the digit to be modified and adjust the values using the **UP** and **DOWN** keys. Then press the **ENTER** button.



HOTSPOT SETUP

USE THIS MODE TO HAVE YOUR WI-FI ENABLED DEVICES CONNECT DIRECTLY TO THE CYBERQ CLOUD. THIS IS HELPFUL IN THE INITIAL SETUP OF THE DEVICE.



1 Hold **UP** and **DOWN** arrows at the same time to access the internal CyberQ Cloud System Menu. Push the **RIGHT** arrow until **WIFI SETUP** appears.



2 Scroll down using the arrow keys and change both **EDIT** and **LOAD** settings to **HOTSPOT**. Use the **ENTER** and **ARROW** keys to change these settings. Then restart it by unplugging the power and plugging it back in.



3 Using a Wi-Fi enabled phone, tablet, or desktop, go to its Wi-Fi Settings and select **HS-MY_CYBERQ_####** (or the custom name you have assigned). If prompted, enter the default password: **1234abcdef**. Once connected, the CyberQ Cloud will briefly display **HOT-SPOT PAIRED!**



4 Using the device you used to connect with Wi-Fi, open a web browser window and type **192.168.101.10** in the address bar to load the internal CyberQ Cloud System web pages. You can also use Hotspot Mode to connect your CyberQ Cloud to your home Wi-Fi.*

(your connected devices will not have internet access during this process)

SHARE MY COOK SETUP

USE SHAREMYCOOK.COM TO MONITOR, CONTROL, AND RECORD YOUR COOKS FROM YOUR COMPUTER, TABLET, OR WI-FI ENABLED SMARTPHONE.



REGISTER DEVICE

1 Go to ShareMyCook.com. Click on 'Register Device' and create an account.

REGISTER ENABLED DEVICE

GENERATE PIN 0000

2 Click 'GENERATE PIN' button on device registration screen. A 4-digit number will be displayed.

3 **Requirement:** Ensure your CyberQ Cloud had already been successfully connected to your home Wi-Fi.



4 Ensure your CyberQ Cloud is in infrastructure mode, that the Cloud Enabled option is turned on, and it is connected to your home Wi-Fi.* Restart the CyberQ Cloud by unplugging the power and plugging it back in.



5 When CyberQ Cloud powers up, you will see **REG PIN: 0000**. Using the arrows keys, adjust the numbers on the CyberQ Cloud to match the PIN on ShareMyCook. Press the **ENTER** button.

YOUR CYBERQ CLOUD HAS BEEN SUCCESSFULLY REGISTERED!



6 Return to ShareMyCook, and within a few minutes, the website will refresh and display CyberQ Cloud registered successfully.

*FOR DETAILED INSTRUCTIONS ON CONNECTING YOUR CYBERQ CLOUD TO YOUR HOME WI-FI, PLEASE REFER TO ADDITIONAL INSERT OR VISIT KB.BBQGURU.COM