

THE GURU GOLF CLUB

5 IN 1

**Flame Spreader/Charcoal Starter*

* Propane bottle and torch head not included



This new tool is really 5 tools in one:

1. A heated grill scraper - Use it with or without flame to scrape and clean your grill or griddle.
2. A grill lifter - Use it to handle a hot or greasy grill.
3. An ash tool - Use it to clean out ashes from the lower door.
4. A fire tool - Use it as a poker to stoke or stir your fire.
5. A powerful and fast, fire starter- Use it as a *flame spreader/charcoal lighter.

* Used to accent or caramelize glazes, ribs, ham, casseroles, etc.

The Guru Golf Club is designed to be used with a standard propane torch. It uses the air and gas that have been mixed by the torch head and sends it to a flame spreader/ burner.

The unit has a flexible extension tube that easily attaches to the torch head at one end and to the swivel connection at the other. The swivel connection allows the user to easily position the flame spreader without twisting the hose connections.

To light the unit, open the valve on the torch and light the golf club flame spreader with an outdoor utility extension lighter. Next, nestle the club under the charcoal to be lit.

You may also pile charcoal on top of the club end. The club can be turned to any angle for lighting but should always be nestled under the charcoal for maximum effect. You don't need to be gentle; it is almost impossible to snuff out the GGC. It was designed for just this purpose.

To shut off the Guru Golf Club, simply turn off propane.

IMPORTANT: You must light the flame spreader head with a torch striker, match or lighter. Self igniting torches will not ignite the Golf club head. You must physically light the head yourself.

CAUTION: As with any gas appliance always use caution and never leave the unit burning unattended.

